

13 PROG

1 MENU 1300

2 MENU PARTY  
TIMER

3 MENU PROG

4 MENU SET  
P i

5 MENU MO-FR  
P i

6 MENU TUE  
P i

7 MENU 0800

|       |    |     |    |
|-------|----|-----|----|
| MO-FR | 1x | WED | 5x |
| SA-SU | 2x | THU | 6x |
| WEEK  | 3x | FRI | 7x |
| MON   | 4x | SAT | 8x |
| TUE   |    | SUN | 9x |

ZGNI-QuickGuide\_D20131001\_V1213\_NL\_EN\_DE\_FR\_IT\_PL\_ES\_Subject to change

13 PROG

8 MENU 1600

9 MENU 1600

10 MENU 1630

11 MENU 1700

12 MENU 1800

13 MENU 1800

14 MENU 18:15

15 MENU SET  
P i

13 PROG

16 MENU HIGH  
P i

17 MENU SET  
P i

18 MENU SAVED  
P i

19 MENU SET  
P 2

MO-FR  
P 2

Snelstart instructie ComfoSense  
 Quick Guide ComfoSense  
 Kurzanleitung ComfoSense  
 Guide Rapide ComfoSense  
 Guida Rapide ComfoSense  
 Skrócona instrukcja obsługi ComfoSense  
 Guía de rápida ComfoSense



